


BPM Calibration Update

E. Brash

August 9, 2018

Sanity Checks for Internal Consistency



Gains and Offsets

- Projected X/Y Position = **slope** * Raw EPICS BPM X/Y Position + **offset**
- A calibration script now exists in

Beam Position at Target ($z = 0$)

$$X(z) = m_x * z + b_x \text{ and } Y(z) = m_y * z + b_y$$

Calculate slopes from A and C BPM's (longest lever arm):

$$m_x = (A_x - C_x)/(A_z - C_z) \text{ and } m_y = (A_y - C_y)/(A_z - C_z)$$

Then calculate b_x and b_y (positions at target)

EPICS data in detector classes

- The previous algorithm requires the BPM information event by event (as the raster information is event by event).
- Fixed the calibrated BPM information from (last) EPICS event in the THcRaster class.
-

THcRaster.h

```
#include "THaEpicsEvtHandler.h"
protected:
    THaEpicsEvtHandler* fEpicsHandler;
```

THcRaster.cxx

(in somewhere like the ReadDatabase method ...)

```
THcAnalyzer *analyzer = dynamic_cast<THcAnalyzer*>(THcAnalyzer::GetInstance());
fEpicsHandler = analyzer->GetEpicsEvtHandler();
```

(in the Decode method ...)

```
if (fEpicsHandler) {
    if (fEpicsHandler->IsLoaded("IPM3H07A.XRAW")){
        BPMXA_raw = atof(fEpicsHandler->GetString("IPM3H07A.XRAW"));
    }
}
```

N.B. Need to be careful with units!!! BPM calibrations are in mm, raster is in cm currently!!

